




YAMAHA

GENUINE

PARTS CATALOGUE

OUTBOARD


CRANKCASE-CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-W0090-41-EK	CRANK-CYLINDER. ASSEMBLY	1	
2	6H4-15100-11-94	CRANKCASE ASSEMBLY	1	
3	90119-08M19-00	BOLT, WITH WASHER	8	
4	90119-06M13-00	BOLT, WITH WASHER	6	
5	93606-12019-00	PIN, DOWEL	2	
6	6H4-11119-00-00	HANGER, ENGINE	1	
7	97313-06014-00	BOLT	2	
8	688-11325-00-00	ANODE	2	
9	98680-04016-00	SCREW.OVAL HEAD	2	
10	6H4-11111-01-94	HEAD, CYLINDER 1	1	
11	6H4-11181-A0-00	GASKET, CYLINDER HEAD 1 .	1	
12	90340-14M00-00	PLUG, STRAIGHT SCREW	1	
13	90430-14115-00	GASKET	1	
14	6H4-11191-01-9M	COVER, CYLINDER HEAD 1 . .	1	
15	6H4-11193-00-00	GASKET, HD.COVER 1	1	
16	90119-08M29-00	BOLT, WITH WASHER	14	
17	6E5-12411-20-00	THERMOSTAT	1	
18	6H4-12413-00-9M	COVER, THERMOSTAT	1	
19	6J8-12414-A0-00	GASKET, COVER	1	
20	97313-06025-00	BOLT	2	
21	92990-06600-00	WASHER, PLATE	2	
22	6H4-41113-00-9M	OUTER COVER, EXHAUST . . .	1	
23	6H4-41111-00-9M	INNER COVER, EXHAUST	1	
24	6H4-41114-A0-00	GASKET, EXHAUST OUTER COVER	2	
25	90445-09M37-00	HOSE	1	
26	90467-08004-00	CLIP	1	
27	97013-06035-00	BOLT	14	
28	92990-06600-00	WASHER, PLATE	14	

CONTINUED ON NEXT FRAME ►


CRANKCASE-CYLINDER


Ref. No.	Part Number	Description	Qty	Remarks
29	NGK-B7HS1-00-00	PLUG, SPARK (NGK B7HS-10)	3	



CRANK-PISTON

Ref.	Part			
No.	Number	Description	Qty	Remarks
1	6H4-11400-14-00	CRANKSHAFT ASSY	1	
2	6H4-11536-00-00	GEAR, DRIVE	1	
3	93306-305U8-00	BEARING	1	
4	93306-305U8-00	BEARING	1	
5	93440-62057-00	BEARING	2	
6	90201-50306-00	WASHER, PLATE	1	
7	6H4-11631-01-95	PISTON (STD)	3	
	6H4-11636-01-00	PISTON (0.50MM O/S)	3	AP
8	6H4-11601-00-00	PISTON RING SET (STD)	3	
	6H4-11601-20-00	PISTON RING SET (0.50MM O/S)	3	AP
9	648-11633-00-00	PIN, PISTON	3	
10	93602-20M02-00	PIN, DOWEL	93	
11	6H4-11641-00-00	WASHER, PISTON PIN	6	
12	6H4-11634-01-00	CLIP, PISTON PIN	6	
13	6H4-15369-A1-00	GASKET, OIL SEAL HOUSING	1	
14	6H4-15396-02-5B	HOUSING, OIL SEAL	1	
15	93102-25M28-00	OIL SEAL	1	
16	93101-16M36-00	OIL SEAL	2	
17	93210-57M09-00	O-RING	1	
18	97313-06020-00	BOLT	1	
19	92990-06600-00	WASHER, PLATE	1	






INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
1	6H5-13610-00-00	REED VALVE ASSY	3	
2	6H4-W0004-00-00	REED SET	1	
3	98580-05016-00	SCREW, PAN HEAD	6	
4	92990-05600-00	WASHER, PLATE	6	
5	6H4-13641-12-94	MANIFOLD 1	1	
	6H4-13641-30-94	MANIFOLD 1	1	UR
6	6H1-14485-00-00	PIPE, JOINT	3	UR
	6H1-14485-00-00	PIPE, JOINT	4	UR
7	6H4-13624-01-94	PLATE, REED VALVE	1	
8	6H4-13621-A1-00	GASKET, VALVE SEAT	2	
9	97313-06020-00	BOLT	12	
10	92990-06600-00	WASHER, PLATE	12	
11	6H4-14198-01-00	GASKET	3	
12	6H4-14406-00-00	HINGE	1	
13	97313-06095-00	BOLT, HEXAGON	6	
14	6H4-14431-01-00	SILENCER, INTAKE 1	1	UR
	6H4-14431-11-00	SILENCER, INTAKE 1	1	UR
15	6H3-14457-01-00	SEAL	3	
16	97895-06040-00	SCREW, PAN HEAD	2	
17	97895-06055-00	SCREW, PAN HEAD	2	
18	90209-06M05-00	WASHER	4	
19	6H4-41257-00-00	ROD, CHOKE 2	2	
20	661-41262-02-00	JOINT, CHOKE LEVER	4	
21	6H4-41271-01-00	KNOB, CHOKE	1	
22	6H4-41259-01-00	ROD, CHOKE 3	1	
23	6J8-41262-00-00	JOINT, CHOKE LEVER	1	
24	6J8-41274-00-00	GROMMET 2	1	
25	6H4-41217-01-00	ROD, ACCEL. LEVER	1	
26	689-41273-00-00	GROMMET	1	UR

CONTINUED ON NEXT FRAME ➤




INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
26	6G1-42748-00-00	GROMMET	1	UR
27	90464-06M19-00	CLAMP	1	
28	90445-07M24-00	HOSE	1	
29	90467-06016-00	CLIP	2	

CARBURETOR


Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-14301-0A-00	CARBURETOR ASSEMBLY 1 .	1	UR
	Φ6H-41430-11-10	UNAVAILABLE IN PRICE BOOK	1	UR
2	6H4-14302-08-00	CARBURETOR ASSEMBLY 2 .	1	UR
	6H4-14302-11-00	CARBURETOR ASSEMBLY 2 .	1	
3	6H4-14303-08-00	CARBURETOR (LOWER)	1	UR
	6H4-14303-11-00	CARBURETOR (LOWER)	1	UR
4	97980-04114-00	SCREW, WITH WASHER	21	
5	663-14592-00-00	SCREW	3	
6	90201-05652-00	WASHER, PLATE	3	
7	663-14523-00-00	SCREW, STOP	1	
8	90501-10326-00	SPRING, COMPRESSION	1	
9	6H2-14578-00-00	COLLAR	1	
10	6H4-14548-00-00	PIN, FLOAT ARM	3	
11	98580-04008-00	SCREW, PAN HEAD	3	
12	663-14159-00-00	CLIP	3	
13	676-14186-00-00	PIN, FLOAT	3	
14	6H4-14985-00-00	FLOAT	3	
15	6H4-14146-00-00	PLATE	3	
16	6H4-14984-00-00	GASKET, FLOAT CHAMBER . .	3	
17	6H4-14980-00-00	BODY, FLOAT CHAMBER	3	
	6H4-14980-10-00	BODY, FLOAT CHAMBER	1	
18	6H3-14992-00-00	SCREW, DRAIN	3	
19	93210-04230-00	O-RING	3	
20	6H4-14947-07-00	JET, NEEDLE	3	
21	676-14943-30-00	JET, MAIN (115)	2	UR
	676-14943-31-00	JET, MAIN (#120) (CENTER) . .	1	UR
	676-14943-31-00	JET, MAIN (#120) (CENTER) . .	2	UR
	676-14943-32-00	JET, MAIN (#125) (CENTER) . .	1	UR
22	676-14966-00-00	CAP	3	


CONTINUED ON NEXT FRAME ➤



CARBURETOR

Ref. No.	Part Number	Description	Qty	Remarks
23	6H4-14948-11-00	JET (60)	3	
24	679-14555-00-00	SPRING	3	
25	692-14923-00-00	SCREW, PILOT	3	
26	6H3-14590-00-00	NEEDLE VALVE ASSY	3	
27	93210-04228-00	O-RING	3	
28	6H4-14147-00-00	O-RING	3	
29	6H4-24452-01-00	COVER	1	
30	6H4-14567-00-00	SCREW	4	
31	6H4-24412-00-00	BODY 1	1	
32	6H4-14592-10-00	SCREW	2	
33	6H4-14561-00-00	O-RING	1	
34	6H4-14562-00-00	O-RING	1	
35	6H4-24413-00-00	BODY 2	1	
36	6H4-24486-00-00	O-RING	1	
37	6L5-24421-00-00	VALVE, CHECK	2	
38	(98990-03006-00)	SCREW, BIND	2	
39	95380-03600-00	NUT	2	
40	97980-05310-00	SCREW, WITH WASHER	2	
41	6H4-86120-00-00	SOLENOID VALVE ASSEMBLY	1	
42	6H5-24434-00-00	GASKET, BODY	2	
43	6H4-24411-00-00	DIAPHRAGM	1	






MANUAL STARTER

Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-15710-02-94	STARTER ASSEMBLY	1	
2	6H4-15711-02-94	CASE, STARTER	1	
3	91690-40018-00	PIN, SPRING	1	
4	6H4-15758-00-94	GUIDE, ROPE	1	
5	97395-06016-00	BOLT	2	
6	92990-06600-00	WASHER, PLATE	2	
7	6H4-15762-00-00	SEAL, RUBBER 2	1	
8	6A0-15789-00-00	DAMPER	1	
9	6F5-15752-00-00	ROLLER, WIRE	1	
10	90387-06M69-00	COLLAR	1	
11	97313-06030-00	BOLT	1	
12	92990-06600-00	WASHER, PLATE	1	
13	95380-06600-00	NUT, HEXAGON	1	
14	6H4-15787-01-00	STAY	1	
15	689-15755-01-00	HANDLE, STARTER	1	
16	6F5-15779-02-00	COVER	1	
17	90580-50M01-00	STARTER ROPE	1	
18	6H4-15714-00-00	DRUM, SHEAVE	1	
19	90510-08002-00	SPRING, SPIRAL	1	
20	6H4-15717-00-00	SHAFT, STARTER	1	
21	90201-065F3-00	WASHER, PLATE	1	
22	97313-06020-00	BOLT	1	
23	95380-06600-00	NUT, HEXAGON	1	
24	676-15741-03-00	PAWL, DRIVE	1	
25	93430-06M02-00	CIRCLIP	1	
26	6H4-15705-00-00	SPRING, DRIVE PAWL	1	
27	97013-06035-00	BOLT	3	
28	92990-06600-00	WASHER, PLATE	3	
29	99530-10014-00	PIN, DOWEL	1	


CONTINUED ON NEXT FRAME ➤



MANUAL STARTER


Ref. No.	Part Number	Description	Qty	Remarks
30	6H4-15771-01-94	STAY 1	1	
31	97313-08030-00	BOLT, HEXAGON	2	
32	92990-08600-00	WASHER, PLATE	2	
33	6H4-15772-02-94	STAY 2	1	
34	97313-06025-00	BOLT	3	
35	92990-06600-00	WASHER, PLATE	3	
36	6H4-15723-01-94	PULLEY, STARTER	1	
37	6J8-81365-00-00	GASKET, HOLE COVER	1	
38	97313-08020-00	BOLT, HEXAGON	3	
39	92990-08600-00	WASHER, PLATE	3	
40	6H4-15774-10-00	STAY 4	1	
41	97013-06012-00	BOLT	1	
42	6H4-15746-00-00	ARM	1	
43	90109-06M04-00	BOLT	1	
44	6H4-15770-10-00	CABLE COMP., STARTER STOP	1	
45	656-15748-00-00	PLUNGER, STARTER STOP ..	1	
46	90501-10227-00	SPRING, COMPRESSION	1	
47	6H4-15747-10-00	LINK	1	
48	661-41262-02-00	JOINT, CHOKE LEVER	2	

ELECTRIC STARTER (40E - ET)




Ref. No.	Part Number	Description	Qty	Remarks
1	6J4-81800-01-00	STARTING MOTOR ASSEMBLY	1	
2	689-81857-11-00	PINION STOPPER SET	1	
3	689-81807-12-00	GEAR ASSY, STARTING MOTOR	1	
4	6F5-81830-11-00	FRONT BRACKET ASSY	1	
5	689-81847-11-00	O-RING	2	
6	689-81809-11-00	WASHER KIT	1	
7	689-81850-12-00	ARMATURE ASSY	1	
8	689-81810-11-00	STATOR ASSY	1	
9	689-81811-11-00	BRUSH 1	1	
10	689-81840-11-00	BRUSH HOLDER ASSY	1	
11	689-81812-11-00	BRUSH 2	1	
12	689-81813-10-00	SPRING, BRUSH	2	
13	689-81820-11-00	REAR BRACKET ASSY	1	
14	689-81826-10-00	BOLT	2	
15	90464-09M13-00	CLAMP	3	
16	97313-08030-00	BOLT, HEXAGON	2	
17	92990-08600-00	WASHER, PLATE	2	
18	97313-08016-00	BOLT, HEXAGON	1	
19	92990-08600-00	WASHER, PLATE	1	
20	6H4-82117-00-00	WIRE, LEAD	1	
21	6H4-81337-01-00	COVER, FLYWHEEL	1	
22	90387-06M65-00	COLLAR	3	
23	90209-06M04-00	WASHER	3	
24	97895-06040-00	SCREW, PAN HEAD	1	
25	97895-06035-00	SCREW, PAN HEAD	2	
26	6J8-15723-E1-00	PULLEY, STARTER	1	
27	6J8-81365-00-00	GASKET, HOLE COVER	1	
28	97011-08016-00	BOLT	3	

CONTINUED ON NEXT FRAME ►



ELECTRIC STARTER (40E - ET)


Ref. No.	Part Number	Description	Qty	Remarks
29	92990-08600-00	WASHER, PLATE	3	
30	6H4-81822-01-98	BRACKET, STRTG MTRSTARTING MOTOR	1	
31	97313-06030-00	BOLT	4	
32	92990-06600-00	WASHER, PLATE	4	
33	97313-08050-00	BOLT, HEXAGON	1	
34	92990-08600-00	WASHER, PLATE	1	
35	95670-06640-00	BOLT, STUD	1	
36	90179-06M24-00	NUT	1	
37	97313-06014-00	BOLT	2	
	97313-06014-00	BOLT	3	
38	92990-06600-00	WASHER, PLATE	2	
39	90338-06M11-00	UNAVAILABLE IN PRICE BOOK	1	
40	6G1-81941-10-00	STARTER RELAY ASSY	1	
41	6H4-81952-00-00	HOLDER, RELAY	1	
42	6H4-81945-00-00	PLATE, SWITCH FITTING	1	
43	90116-06M22-00	BOLT, STUD	1	
44	95380-06600-00	NUT, HEXAGON	2	
45	92990-06600-00	WASHER, PLATE	1	



FUEL SYSTEM

Ref. No.	Part Number	Description	Qty	Remarks
1	6G1-24304-02-00	FUEL PIPE JOINT COMP. 1 ...	1	
2	97395-06025-00	BOLT, HEXAGON	1	
3	92990-06600-00	WASHER, PLATE	1	
4	90467-08004-00	CLIP	2	
5	655-24560-01-00	FILTER ASSEMBLY	1	
6	6F5-24563-00-00	ELEMENT, FILTER	1	
7	93210-37M25-00	O-RING	1	
8	655-24521-01-00	CUP, FILTER	1	
9	6H4-24566-01-00	BRACKET, FILTER	1	
10	97013-06012-00	BOLT	1	
11	95380-08600-00	NUT	1	
12	6H4-24314-00-00	PIPE 4	1	
13	90467-08004-00	CLIP	2	
14	6A0-24410-05-00	FUEL PUMP ASSEMBLY	1	
15	648-24411-00-00	DIAPHRAGM	1	
16	648-24424-00-00	SEAT, SPRING	1	
17	648-24423-00-00	SPRING, DIAPHRAGM	1	
18	648-24434-01-00	GASKET, BODY	1	
19	6A0-24421-01-00	VALVE, CHECK	2	
20	6A0-14325-00-00	SCREW, PAN HEAD	2	
21	(95380-03100-00)	NUT	2	
22	648-24435-02-00	GASKET, BODY 2	1	
23	663-24411-00-00	DIAPHRAGM	1	
24	648-24413-01-00	BODY 2	1	
25	98580-05530-00	SCREW, PAN HEAD	3	
26	92990-05100-00	WASHER, SPRING	3	
27	650-24431-A0-00	GASKET, FUEL PUMP 1	1	
28	97395-06040-00	BOLT	2	
29	92990-06600-00	WASHER, PLATE	2	

CONTINUED ON NEXT FRAME ➤




FUEL SYSTEM

Ref. No.	Part Number	Description	Qty	Remarks
30	90445-09063-00	HOSE	1	
31	688-24378-00-00	PIPE, JOINT 4	2	
32	90445-09057-00	HOSE	2	
33	6H4-24313-00-00	PIPE 3	1	
34	6H4-24312-00-00	PIPE 2	1	
35	90467-08004-00	CLIP	10	
36	6H4-24311-00-00	PIPE, FUEL 1	1	
37	90464-16039-00	CLAMP	3	


FUEL TANK

Ref. No.	Part Number	Description	Qty	Remarks
1	6Y1-W2420-42-24	FUEL TANK ASSEMBLY	1	
2	6Y1-24244-20-00	GRAPHIC, SIDE	1	
3	6Y1-24610-00-00	CAP ASSEMBLY	1	
4	6Y1-24260-02-00	FUEL METER ASSEMBLY	1	
5	6Y1-24268-00-00	GASKET, FUEL METER	1	
6	6Y1-24329-00-00	SEAL	4	
7	98586-05016-00	SCREW, PAN HEAD	4	
8	6Y1-24256-50-00	GRAPHIC, FUEL TANK 9	1	
9	6Y1-24306-51-00	FUEL PIPE COMP. 1	1	
10	90445-11M06-00	HOSE (L:2050MM)	1	
11	6Y1-24360-51-00	PRIMER PUMP ASSY	1	
12	90445-11M05-00	HOSE (L:850MM)	1	
13	650-24351-51-00	BAND 1	4	
14	6G1-24305-01-00	FUEL PIPE JOINT COMP. 2	1	
15	93210-08287-00	O-RING	1	
16	6Y1-24305-02-00	FUEL PIPE JOINT COMP. 2	1	
17	93210-08287-00	O-RING	1	
18	656-W2810-02-00	TOOL KIT	1	
19	ABB-FLUSH-JD-00	JET DRIVE FLUSH	1	




TOP COWLING


Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-42610-U1-EK	TOP COWLING ASSEMBLY . . .	1	
2	6H4-15761-00-00	SEAL, RUBBER 1	1	
3	6H4-42615-00-00	SEAL	1	
4	6H4-42651-00-00	HOOK	1	
5	6H4-42652-00-00	HOOK	1	
6	90266-04M01-00	RIVET	4	
7	6H4-42613-00-EK	MOLDING, AIR DUCT	1	
8	97395-06016-00	BOLT	4	
9	92990-06600-00	WASHER, PLATE	4	
10	6H4-42686-02-00	EMBLEM, FRONT	1	UR
	6H4-42686-A0-00	EMBLEM, FRONT	1	UR
11	6H4-42687-01-00	EMBLEM, REAR	1	UR
	6H4-42687-A1-00	EMBLEM, REAR	1	UR
12	6H4-W0070-42-00	GRAPHIC SET	1	
13	6H4-42682-10-00	MARK, COWLING	1	
14	6H4-42684-A0-00	MARK, COWLING 4	2	



TOP COWLING (40E - ET)

Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-42610-44-EK	TOP COWLING ASSEMBLY ...	1	
2	6H4-42615-00-00	SEAL	1	
3	6H4-42651-00-00	HOOK	1	
4	6H4-42652-00-00	HOOK	1	
5	90266-04M01-00	RIVET	4	
6	6H4-42613-10-EK	MOLDING, AIR DUCT	1	
7	97395-06016-00	BOLT	4	
8	92990-06600-00	WASHER, PLATE	4	
9	6H4-42686-11-00	EMBLEM, FRONT	1	UR
	6H4-42686-E0-00	EMBLEM, FRONT	1	UR
10	6H4-42687-10-00	EMBLEM, REAR	1	UR
	6H4-42687-E0-00	EMBLEM, REAR (35E)	1	UR
11	6H4-W0070-42-00	GRAPHIC SET	1	
12	6H4-42682-40-00	MARK, COWLING	1	
13	6H4-13436-40-00	MARK	1	
14	6H1-2177H-01-00	DISK CAP 2	1	
15	6H3-21732-00-00	SEAL 1	1	
16	6H3-21735-00-00	SEAL 2	1	
17	6H1-42694-00-00	BAND	1	
18	90338-05M12-00	PLUG	1	
19	90183-05M06-00	NUT, SPRING	1	
20	6H4-42684-A0-00	MARK, COWLING 4	2	






BOTTOM COWLING


Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-42711-05-EK	BOTTOM COWLING	1	
2	90338-05M03-00	PLUG	1	
3	6H4-42815-00-00	LEVER, CLAMP	1	
4	90206-12052-00	WASHER, WAVE	1	
5	90386-12069-00	BUSH	2	
6	6H4-42816-00-00	LEVER, CLAMP	1	
7	90201-06M02-00	WASHER, PLATE	1	
8	97313-06010-00	BOLT, HEXAGON	1	
9	6H4-42726-00-00	GROMMET	1	UR
	6H5-42726-00-00	GROMMET	1	UR
10	6H4-48531-00-94	BRACKET, REMOTE CONTROL 1	1	
11	6H4-48532-00-94	BRACKET, REMOTE CONTROL 2	1	
12	97313-05016-00	BOLT, HEXAGON	1	
13	92990-05600-00	WASHER, PLATE	1	
14	97313-06020-00	BOLT	2	
15	92990-06600-00	WASHER, PLATE	2	
16	6H4-42724-00-00	GROMMET	1	
17	6E5-44391-00-00	NIPPLE, HOSE	1	
18	6H4-42716-00-00	RUBBER, SEAL 1	1	
19	682-42727-00-00	GROMMET	1	
20	90480-09M21-00	GROMMET	4	
21	90387-06M41-00	COLLAR	4	
22	90201-06416-00	WASHER, PLATE	4	
23	97313-06030-00	BOLT	4	
24	6H4-42741-00-00	APRON 1	1	
25	97395-06016-00	BOLT	4	
26	92990-06600-00	WASHER, PLATE	4	

CONTINUED ON NEXT FRAME ►



BOTTOM COWLING


Ref. No.	Part Number	Description	Qty	Remarks
27	6E9-82575-01-00	ENGINE STOP SWITCH ASSEMBLY	1	
28	682-82556-00-00	STOPPER	1	
29	6H4-82537-00-00	ATTACHMENT, STOP SWITCH	1	
30	6J8-85410-00-00	EMERGENCY SIGNAL LIGHT ASSY	1	
31	6H4-85415-10-00	MARK, SIGNAL LAMP	1	
32	6H3-42727-00-00	GROMMET	1	



BRACKET 1


Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-43111-04-EK	BRACKET, CLAMP	1	
2	6H4-43112-04-EK	BRACKET, CLAMP	1	
3	6E5-82148-00-00	WIRE, LEAD 4	1	
4	98580-06008-00	SCREW, PAN HEAD	1	
5	616-43118-00-EK	HANDLE, TRANSOM CLPTRANSOM CLAMP	2	
6	90243-04M00-00	PIN	2	
7	90149-14M12-00	SCREW	2	
8	648-43114-01-00	PAD, TRANSOM CLAMP	2	
9	6J8-43131-01-00	BOLT, CLAMP BRACKET	1	
10	90386-22M69-00	BUSH	2	
11	6J8-43113-01-00	PLATE, CLAMP BRACKET ...	1	
12	90201-22428-00	WASHER, PLATE	2	
13	90185-22043-00	NUT, SELF-LOCKING	2	
14	6G5-43145-00-00	CAP, CLAMP BRACKET	2	
15	90101-08339-00	BOLT	1	
16	90387-08M03-00	COLLAR	1	
17	92990-08600-00	WASHER, PLATE	1	
18	95380-08600-00	NUT	1	
19	6J8-43311-04-EK	BRACKET, SWIVEL 1	1	
20	93700-06M03-00	NIPPLE, GREASE	3	
21	663-45119-00-00	CAP, GREASE NIPPLE	3	
22	6J8-42528-00-00	PLATE, FRICTION	1	
23	689-43373-01-00	SEAL, DAMPER	1	
24	90105-06M18-00	BOLT, WASHER BASED	1	
25	6H4-42510-12-EK	STEERING BRACKETASSEMBLY	1	
26	90386-30M77-00	BUSH	2	
27	90201-30M00-00	WASHER, PLATE	1	

CONTINUED ON NEXT FRAME ►



BRACKET 1


Ref. No.	Part Number	Description	Qty	Remarks
28	90386-30M78-00	BUSH	1	
29	93210-29M94-00	O-RING	2	
30	90386-30M60-00	BUSH	1	
31	6H4-44551-01-EK	HOUSING, LWR, MOUNT LOWER MOUNT	1	
32	93410-28M06-00	CIRCLIP	1	
33	6H4-42121-02-5B	BRACKET	1	
34	90116-10175-00	BOLT, STUD	2	
35	90185-10051-00	NUT, SELF-LOCKING	2	
36	6H4-44557-00-00	MOUNT DAMPER, LOWER FRONT	1	UR
	6H4-44557-10-00	MOUNT DAMPER, LOWER FRONT	1	
37	6H4-44553-01-00	COVER, LOWER MOUNT	1	
38	97395-08025-00	BOLT	4	
39	92990-08600-00	WASHER, PLATE	4	
40	97395-10060-00	BOLT	2	
41	92990-10600-00	WASHER, PLATE	2	
42	6H4-82127-00-00	WIRE, LEAD 2	1	
43	6H4-44514-00-00	MOUNT DAMPER, UPPER SIDE	2	
44	90101-08M86-00	BOLT	2	
45	90201-09425-00	WASHER, PLATE	2	
46	90185-08045-00	NUT, SELF-LOCKING	2	
47	6H4-44511-00-94	COVER, UPPER MOUNT	1	
48	97090-08035-00	BOLT	3	
49	92990-08100-00	WASHER, SPRING	3	
50	90101-10M58-00	BOLT	4	
51	92995-10600-00	WASHER	8	
52	90201-12426-00	WASHER, PLATE	4	
53	95380-10600-00	NUT	8	



BRACKET 1 (40ET)

Ref. No.	Part Number	Description	Qty	Remarks
1	6H5-43111-02-EK	BRACKET, CLAMP	1	
2	90465-11M10-00	CLAMP	1	
3	6H5-43112-03-EK	BRACKET, CLAMP	1	
4	6E5-82148-00-00	WIRE, LEAD 4	1	
5	98580-06008-00	SCREW, PAN HEAD	1	
6	6H5-43128-01-EK	SPACER, CLAMP BRKTCLAMP BRACKET	1	
7	6H1-45251-02-00	ANODE	1	
8	6H1-44526-00-00	PLATE	1	
9	90201-06M31-00	WASHER, PLATE	2	
10	97395-06012-00	BOLT	2	
11	97395-06016-00	BOLT	2	
12	92995-06100-00	WASHER, SPRING	2	
13	92990-06600-00	WASHER, PLATE	2	
14	6J8-43131-01-00	BOLT, CLAMP BRACKET	1	
15	90386-22M15-00	BUSH	2	
16	6J8-43113-01-00	PLATE, CLAMP BRACKET ...	1	
17	90201-22428-00	WASHER, PLATE	2	
18	90185-22043-00	NUT, SELF-LOCKING	2	
19	6G5-43145-00-00	CAP, CLAMP BRACKET	2	
20	6H5-43311-03-EK	BRACKET, SWIVEL 1	1	
21	6J8-42528-00-00	PLATE, FRICTION	1	
22	689-43373-01-00	SEAL, DAMPER	1	
23	90105-06M18-00	BOLT, WASHER BASED	1	
24	676-43160-02-00	TILT ROD ASSY	1	
25	676-43165-00-00	PLATE, TILT LOCK	1	
26	91690-30012-00	PIN, SPRING	1	
27	90502-10M04-00	SPRING, CONICAL	1	
28	93700-06M03-00	NIPPLE, GREASE	3	


CONTINUED ON NEXT FRAME ►



BRACKET 1 (40ET)


Ref. No.	Part Number	Description	Qty	Remarks
29	663-45119-00-00	CAP, GREASE NIPPLE	3	
30	97395-06010-00	BOLT, HEXAGON	1	
31	92990-06600-00	WASHER, PLATE	1	
32	90446-10M01-00	HOSE	2	
33	6H5-43181-02-00	LEVER, TILT STOP	1	
34	6H5-43185-02-00	LEVER, TILT STOP	1	
35	90386-10M16-00	BUSH	3	
36	92990-10600-00	WASHER, PLATE	2	
37	90501-10M21-00	SPRING, COMPRESSION	1	
38	91490-30030-00	PIN, COTTER	1	
39	663-43318-00-00	COVER	2	
40	90386-10M19-00	BUSH	1	
41	6H5-43126-02-00	PIN, UPPER SHOCK MOUNT ..	1	
42	90386-12M65-00	BUSH	1	
43	90386-12M64-00	BUSH	2	
44	93410-12M08-00	CIRCLIP	1	
45	90116-18M21-00	BOLT, STUD	1	
46	90170-18M10-00	NUT	2	
47	92990-18600-00	WASHER	1	
48	90386-18M44-00	BUSH	2	
49	6H5-82127-00-00	WIRE, LEAD 2	1	
50	6H5-82149-00-00	WIRE, LEAD 3	1	
51	6H4-42510-02-EK	STEERING BRACKETASSEMBLY	1	
52	93210-29M94-00	O-RING	2	
53	90386-30M60-00	BUSH	1	
54	90386-30M77-00	BUSH	2	
55	90201-30M00-00	WASHER, PLATE	1	
56	90386-30M78-00	BUSH	1	

CONTINUED ON NEXT FRAME ➤



BRACKET 1 (40ET)


Ref. No.	Part Number	Description	Qty	Remarks
57	6H4-44551-01-EK	HOUSING, LWR, MOUNTLOWER MOUNT	1	
58	93410-28M06-00	CIRCLIP	1	
59	6H4-48511-51-EK	HOOK STEERING	1	
60	90116-10175-00	BOLT, STUD	2	
61	90185-10051-00	NUT, SELF-LOCKING	2	
62	6H4-44557-00-00	MOUNT DAMPER, LOWER FRONT	1	UR
	6H4-44557-10-00	MOUNT DAMPER, LOWER FRONT	1	
63	6H4-44553-01-00	COVER, LOWER MOUNT	1	
64	97395-08025-00	BOLT	4	
65	92990-08600-00	WASHER, PLATE	4	
66	97395-10060-00	BOLT	2	
67	92990-10600-00	WASHER, PLATE	2	
68	6H4-44514-00-00	MOUNT DAMPER, UPPER SIDE	2	
69	90101-08M86-00	BOLT	2	
70	90201-09425-00	WASHER, PLATE	2	
71	90185-08045-00	NUT, SELF-LOCKING	2	
72	6H4-44511-00-94	COVER, UPPER MOUNT	1	
73	97090-08035-00	BOLT	3	
74	92990-08100-00	WASHER, SPRING	3	
75	90101-12M65-00	BOLT	4	
76	92990-12200-00	WASHER, PLAIN	8	
77	90201-12426-00	WASHER, PLATE	4	
78	95380-12600-00	NUT	8	



BRACKET 2


Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-43160-01-00	TILT ROD ASSY	1	
2	676-43165-00-00	PLATE, TILT LOCK	1	
3	91690-30010-00	PIN, SPRING	1	
4	90502-10M04-00	SPRING, CONICAL	1	
5	6J8-43181-01-00	LEVER, TILT STOP	1	
6	90506-12M25-00	SPRING, TENSION	1	
7	90249-12M28-00	PIN	1	
8	93430-10M00-00	CIRCLIP	1	
9	90202-12031-00	WASHER, PLATE	2	
10	682-43318-01-00	COVER	1	
11	6J8-43627-00-00	STOPPER	2	
12	90249-12M27-00	PIN	2	
13	93430-10M00-00	CIRCLIP	2	
14	90202-12031-00	WASHER, PLATE	2	
15	90206-12M16-00	WASHER, WAVE	2	
16	6J8-43614-00-00	PLATE, TILT LOCK	1	
17	6J8-43615-00-00	PLATE, TILT LOCK	1	
18	6J8-43613-01-00	ARM, TILT LOCK	1	
19	6H4-43659-00-00	SHAFT, REVERSE LOCK	1	
20	6J8-43611-01-00	SHAFT, TILT LOCK	1	
21	90387-07M64-00	COLLAR	1	
22	93430-06M02-00	CIRCLIP	1	
23	99080-05600-00	CIRCLIP (93430-05027-00)	1	
24	90506-32M22-00	SPRING, TENSION	2	
25	91490-20015-00	PIN, COTTER	2	
26	6J8-43631-00-00	LEVER, TILT	1	
27	6J8-43633-00-00	COVER, TILT LEVER	1	
28	90508-18M23-00	SPRING, TORSION	1	
29	6H4-43616-00-00	ROD, TILT LOCK	1	

CONTINUED ON NEXT FRAME ➤



BRACKET 2


Ref. No.	Part Number	Description	Qty	Remarks
30	6J8-43641-00-00	LEVER, TILT	1	
31	90249-06M24-00	PIN	1	
32	6J8-43617-00-00	ROD, TILT LOCK	1	
33	99080-05600-00	CIRCLIP (93430-05027-00)	1	
34	6J8-43681-01-00	LEVER, SHALLOW WATER DRIVE 1	1	
35	6J8-43673-00-00	WASHER 1	2	
36	6J8-43631-10-00	LEVER, TILT	1	
37	6J8-43633-00-00	COVER, TILT LEVER	1	
38	6H4-43616-00-00	ROD, TILT LOCK	1	
39	6J8-43641-00-00	LEVER, TILT	1	
40	6J8-43617-10-00	ROD, TILT LOCK	1	
41	6J8-43186-00-00	LEVER	1	
42	6J8-43187-00-00	LEVER 2	1	
43	90508-25M21-00	SPRING, TORSION	1	
44	90249-07M25-00	PIN	1	
45	99080-05600-00	CIRCLIP (93430-05027-00)	1	
46	6J8-41262-00-00	JOINT, CHOKE LEVER	3	
47	6J8-43616-10-00	ROD, TILT LOCK	1	
48	90508-20M22-00	SPRING, TORSION	1	



STEERING

Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-W0084-04-EK	STEERING HNDLE.ASSEMBLY	1	
2	6H4-42111-01-EK	HANDLE, STEERING	1	
3	664-42119-00-00	GRIP, STEERING HANDLE ...	1	
4	6G1-42177-00-00	RUBBER, HANDLE	1	
5	6L2-42137-00-00	INDICATOR, THROTTLE	1	
6	90269-02M09-00	RIVET	1	
7	98680-05525-00	SCREW.OVAL HEAD	1	
8	92990-10600-00	WASHER, PLATE	1	
9	90501-23215-00	SPRING, COMPRESSION	1	
10	6H4-42138-01-00	LEVER, THROTTLE	1	
11	90386-08032-00	BUSH	1	
12	6H4-42159-00-00	STAY	1	
13	98580-05016-00	SCREW, PAN HEAD	4	
14	92901-05600-00	WASHER, PLATE	4	
15	6H4-42131-00-00	COVER, HANDLE STEERING ..	1	
16	6H4-26311-03-00	CABLE, THROTTLE 1	1	
17	90101-12M37-00	BOLT	1	
18	90386-12089-00	BUSH	1	
19	92990-12200-00	WASHER, PLAIN	1	
20	90202-12092-00	WASHER, PLATE	2	
21	90201-12537-00	WASHER, PLATE	2	
22	90206-12054-00	WASHER, WAVE	1	
23	90185-12058-00	NUT, SELF-LOCKING	1	
24	656-42126-01-00	FRICITION, STEERING HANDLE GRIP	1	
25	97395-06020-00	BOLT, HEXAGON	1	
26	90185-06062-00	NUT, SELF-LOCKING	1	


CONTROL ENGINE (40 MANUAL)



Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-41213-14-00	CAM, ACCEL.	1	UR
2	6H4-41213-A1-00	CAM, ACCEL.	1	UR
	90109-06M43-00	BOLT	1	
3	6H4-41632-01-00	LEVER, MAGNETO CONTROL .	1	
4	90508-26M20-00	SPRING, TORSION	1	
5	6G5-41636-01-00	ROD, MAGNETO CONTROL ..	1	
6	6H4-41237-00-00	JOINT, LINK	1	
7	95380-05600-00	NUT	1	
8	90387-06M19-00	COLLAR	1	
9	97313-06025-00	BOLT	1	
10	90157-06M13-00	SCREW, PAN HEAD	1	
11	95380-06600-00	NUT, HEXAGON	1	
12	688-44194-00-00	CAP	1	
13	6H4-44111-00-00	HANDLE, GEAR SHIFT	1	
14	682-44132-00-00	BUSHING	1	
15	6H4-44121-02-00	LEVER, SHIFT ROD	1	
16	91690-30318-00	PIN, SPRING	1	
17	6H4-44116-00-00	SPRING	1	
18	682-44117-00-00	BRACKET	1	
19	97313-06016-00	BOLT	1	
20	6H4-44125-01-00	LEVER, SHIFT ROD	1	
21	91690-30316-00	PIN, SPRING	1	
22	6F5-41662-00-00	BRACKET	1	
23	97313-06020-00	BOLT	2	
24	92990-06600-00	WASHER, PLATE	2	
25	6H4-44143-00-00	ROD, SHIFT	1	
26	91790-05020-00	PIN, CLEVIS	1	
27	92990-05600-00	WASHER, PLATE	1	
28	91490-16010-00	PIN, COTTER	1	

CONTINUED ON NEXT FRAME ➤


CONTROL ENGINE (40 MANUAL)



Ref. No.	Part Number	Description	Qty	Remarks
29	648-44146-00-00	CONNECTOR, SHIFT ROD	1	
30	6H4-41633-01-00	LEVER, MAGNETO CONTROL .	1	
31	97313-05020-00	BOLT, HEXAGON	1	
32	92990-05600-00	WASHER, PLATE	1	
33	90113-05M06-00	BOLT, SET	1	
34	95303-05700-00	NUT	1	
35	663-48344-00-00	CABLE END, REMOTE CONTROL	1	
36	90468-18008-00	CLIP	1	
37	90170-07021-00	NUT	1	

CONTROL ENGINE (40E - ET)


Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-41213-04-00	CAM, ACCEL.	1	UR
	6H4-41213-E1-00	CAM, ACCEL.	1	UR
2	90109-06M43-00	BOLT	1	
3	6H4-41632-01-00	LEVER, MAGNETO CONTROL .	1	
4	90508-26M20-00	SPRING, TORSION	1	
5	6G5-41636-01-00	ROD, MAGNETO CONTROL ..	1	
6	6H4-41237-00-00	JOINT, LINK	1	
7	95380-05600-00	NUT	1	
8	90387-06M19-00	COLLAR	1	
9	97313-06025-00	BOLT	1	
10	90157-06M13-00	SCREW, PAN HEAD	2	
11	95380-06600-00	NUT, HEXAGON	2	
12	688-44194-00-00	CAP	2	
13	6H4-44111-10-00	HANDLE, GEAR SHIFT	1	
14	682-44132-00-00	BUSHING	1	
15	6H4-44121-02-00	LEVER, SHIFT ROD	1	
16	91690-30318-00	PIN, SPRING	1	
17	6H4-44116-00-00	SPRING	1	
18	682-44117-00-00	BRACKET	1	
19	97313-06016-00	BOLT	1	
20	6H4-44125-01-00	LEVER, SHIFT ROD	1	
21	91690-30316-00	PIN, SPRING	1	
22	6F5-41662-00-00	BRACKET	1	
23	97313-06020-00	BOLT	2	
24	92990-06600-00	WASHER, PLATE	2	
25	6H4-44143-00-00	ROD, SHIFT	1	
26	91790-05020-00	PIN, CLEVIS	1	
27	92990-05600-00	WASHER, PLATE	1	
28	91490-16010-00	PIN, COTTER	1	




CONTINUED ON NEXT FRAME ➤

CONTROL ENGINE (40E - ET)


Ref. No.	Part Number	Description	Qty	Remarks
29	648-44146-00-00	CONNECTOR, SHIFT ROD	1	
30	90170-07021-00	NUT	1	





UPPER CASING


Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-45111-00-EK	CASING, UPPER	1	UR
	6H4-45111-10-EK	CASING, UPPER	1	
2	93606-12019-00	PIN, DOWEL	2	
3	97395-08080-00	BOLT, HEXAGON	8	
4	92990-08600-00	WASHER, PLATE	8	
5	6H4-41137-00-94	GUIDE, EXHAUST	1	
6	6H4-45114-A1-00	GASKET, UPPER CASING	1	
7	6H4-41134-A0-00	GASKET, EXHAUST MANIFOLD	1	
8	6H4-41131-01-5B	MANIFOLD, EXT. 1	1	
9	6H4-14711-00-5B	MUFFLER 1	1	UR
	6H4-14711-10-5B	MUFFLER 1	1	UR
10	663-45123-00-00	GASKET, MUFFLER	1	
11	97395-08030-00	BOLT	7	
12	92990-08600-00	WASHER, PLATE	7	
13	97395-08030-00	BOLT	2	
14	92990-08100-00	WASHER, SPRING	2	
15	6H4-41133-00-00	GASKET, EXHAUST MANIFOLD 1	1	
16	6H4-45113-A0-00	GASKET, UPPER CASING	1	
17	93606-12019-00	PIN, DOWEL	2	



LOWER DRIVE 1

Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-45300-02-EK	LOWER UNIT ASSEMBLY	1	UR
	6H4-45300-12-EK	LOWER UNIT ASSEMBLY	1	UR
2	6H4-45301-01-EK	LOWER CASING	1	
3	93315-32224-00	BEARING	1	
4	6H4-45536-00-00	SLEEVE, DRIVE SHAFT	1	
5	663-45587-01-10	SHIM (T:0.10MM)	1	UR
	663-45587-01-12	SHIM (T:0.12MM)	1	UR
	663-45587-01-15	SHIM (T:0.15MM)	1	UR
	663-45587-01-18	SHIM (T:0.18MM)	1	UR
	663-45587-01-30	SHIM (T:0.30MM)	1	UR
	663-45587-01-40	SHIM (T:0.40MM)	1	UR
	663-45587-01-50	SHIM (T:0.50MM)	1	UR
6	93332-00001-00	BEARING	1	
7	90340-08M04-00	PLUG, STRAIGHT SCREW	2	
8	90430-08020-00	GASKET	3	
9	688-45341-00-00	PLUG, DRAIN	1	
10	6H4-45321-01-00	PLATE	1	
11	93210-49046-00	O-RING	1	
12	6G1-44147-00-00	BOOT, SHIFT ROD	1	
13	97395-06016-00	BOLT	1	
14	92990-06600-00	WASHER, PLATE	1	
15	6H4-45378-00-00	NIPPLE, HOSE	1	
16	90209-10M14-00	WASHER	1	
17	90445-07M31-00	HOSE	1	
	90445-07ME9-00	HOSE (L120)	1	UR
18	6E5-83558-00-00	END, NIPPLE	1	
19	90465-11M10-00	CLAMP	2	
20	6J8-44311-00-00	HOUSING, WATER PUMP	1	
21	663-44322-00-00	INSERT, CARTRIDGE	1	


CONTINUED ON NEXT FRAME ➤



LOWER DRIVE 1


Ref. No.	Part Number	Description	Qty	Remarks
22	6H4-44352-02-00	IMPELLER	1	
23	663-44315-00-00	GASKET, WATER PUMP	1	
24	663-44366-00-00	DAMPER, WATER SEAL	1	
25	90280-03024-00	KEY, WOODRUFF	1	
26	663-44341-00-94	HOUSING, WATER PUMP	1	
27	93101-23070-00	OIL SEAL	2	
28	93210-41042-00	O-RING	1	
29	663-44316-00-00	GASKET, WATER PUMP	1	
30	663-44323-00-00	OUTER PLATE, CARTRIDGE ..	1	
31	663-44324-00-00	GASKET, CARTRIDGE	1	
32	93604-08062-00	PIN, DOWEL	2	
33	97395-08055-00	BOLT	2	
34	97395-08045-00	BOLT	2	
35	6H4-45501-00-00	DRIVE SHAFT COMP.	1	UR
	6H4-45501-10-00	DRIVE SHAFT COMP.	1	UR
36	6H4-45551-00-00	PINION	1	
37	90170-12138-00	NUT	1	
38	6H4-45560-00-00	GEAR	1	
39	93332-000V4-00	BEARING	1	
40	6H4-45567-01-10	SHIM (T:0.10MM)	1	UR
	6H4-45567-01-12	SHIM (T:0.12MM)	1	UR
	6H4-45567-01-15	SHIM (T:0.15MM)	1	UR
	6H4-45567-01-18	SHIM (T:0.18MM)	1	UR
	6H4-45567-01-30	SHIM (T:0.30MM)	1	UR
	6H4-45567-01-40	SHIM (T:0.40MM)	1	UR
	6H4-45567-01-50	SHIM (T:0.50MM)	1	UR
41	679-45611-01-00	SHAFT, PROPELLER	1	
42	676-45635-00-00	PLUNGER, SHIFT	1	
43	663-45634-00-00	SLIDE, SHIFT	1	

CONTINUED ON NEXT FRAME ➤



LOWER DRIVE 1


Ref. No.	Part Number	Description	Qty	Remarks
44	6H4-45631-00-00	CLUTCH, DOG	1	
45	90250-06023-00	PIN, STRAIGHT	1	
46	663-45633-00-00	RING, CROSS PIN	1	
47	90201-22429-00	WASHER, PLATE	1	
48	90501-16M01-00	SPRING, COMPRESSION	1	
49	6H4-44150-01-00	SHIFT CAM ASSEMBLY	1	UR
	6H4-44150-12-00	SHIFT CAM ASSEMBLY	1	
50	6H4-44160-00-00	DETENT COMP.	1	
51	6H4-45571-00-00	GEAR	1	
52	679-45331-00-94	HOUSING, BEARING	1	
53	93306-00702-00	BEARING	1	
54	663-45577-01-10	SHIM (T:0.10MM)	1	UR
	663-45577-01-12	SHIM (T:0.12MM)	1	UR
	663-45577-01-15	SHIM (T:0.15MM)	1	UR
	663-45577-01-18	SHIM (T:0.18MM)	1	UR
	663-45577-01-30	SHIM (T:0.30MM)	1	UR
	663-45577-01-40	SHIM (T:0.40MM)	1	UR
	663-45577-01-50	SHIM (T:0.50MM)	1	UR
55	663-45576-00-00	WASHER, THRUST	1	
56	93210-66M98-00	O-RING	1	
57	93317-22204-00	BEARING	1	
58	93101-22067-00	OIL SEAL	2	
59	90214-48M03-00	WASHER, CLAW	1	
60	697-45384-00-00	NUT	1	
61	90282-04010-00	KEY, STRAIGHT	1	
62	90209-08M02-00	WASHER	4	



LOWER DRIVE 2


Ref. No.	Part Number	Description	Qty	Remarks
1	663-45376-00-94	GUIDE, SEAL DAMPER	1	
2	688-45375-00-00	DAMPER, SEAL	1	
3	688-45214-02-00	COVER, WATER INLET	1	
4	688-45215-02-00	COVER, WATER INLET	1	
5	98680-05535-00	SCREW, OVAL HEAD	1	
6	90185-05002-00	NUT, SELF-LOCKING	1	
7	664-45371-01-00	TAB-TRIM	1	
8	97375-08075-00	BOLT	1	
9	92990-08100-00	WASHER, SPRING	1	
10	92990-08600-00	WASHER, PLATE	1	
11	95380-08600-00	NUT	1	
12	93606-12019-00	PIN, DOWEL	2	
13	97395-10040-00	BOLT	4	
14	92990-10100-00	WASHER, SPRING	4	
15	92990-10600-00	WASHER, PLATE	4	
16	97395-08085-00	BOLT	1	
17	92990-08100-00	WASHER, SPRING	1	
18	92990-08600-00	WASHER, PLATE	1	
19	90202-12060-00	WASHER, PLATE	1	
20	6H4-44361-00-00	TUBE, WATER	1	UR
	6H4-44361-10-00	TUBE, WATER	1	UR
21	90430-12072-00	GASKET	1	
22	663-44367-00-00	DAMPER, WATER SEAL	1	
23	663-45987-02-00	SPACER	1	
24	670-45997-02-00	SPACER	1	
25	92990-16200-00	WASHER, PLAIN	1	
26	90171-16011-00	NUT, CASTLE	1	
27	91490-30030-00	PIN, COTTER	1	
28	663-45930-00-98	PROPELLER (3X10-1/4"X14"-G)	1	UR

CONTINUED ON NEXT FRAME ➤



LOWER DRIVE 2

Ref. No.	Part Number	Description	Qty	Remarks
28	663-45941-01-EL	PROPELLER (3X10-3/4"X17"-G)	1	UR
	663-45947-02-EL	PROPELLER (3X11-5/8"X11"-G)	1	UR
	663-45949-01-EL	PROPELLER (3X10-3/4"X16"-G)	1	UR
	663-45956-01-EL	PROPELLER (3X11-3/4"X10"-G)	1	UR
	663-45958-01-EL	PROPELLER (3X11-1/4"X14"-G)	1	UR
	663-45970-60-98	PROPELLER (3X11-3/4"X12"-G)	1	UR
	663-45972-60-98	PROPELLER (3X12"X11"-G) . .	1	UR
	663-45974-60-98	PROPELLER (3X11-1/2"X13"-G)	1	UR
	663-45976-00-98	PROPELLER (3X10-1/4"X15"-G)	1	UR
	663-45978-00-98	PROPELLER (3X10-1/4"X16"-G)	1	UR
	6H5-45943-00-EL	PROPELLER (3X10"X15"-G) . .	1	UR
	6H5-45945-00-EL	PROPELLER (3X10-3/8"X13"-G)	1	UR
	6H5-45952-00-EL	PROPELLER (3X10-5/8"X12"-G)	1	UR
	6H5-45958-00-EL	PROPELLER (3X10-1/4"X14"-G)	1	UR
29	663-45981-10-00	DAMPER, PROPELLER	1	
30	663-45986-00-94	RING, DEFLECTOR	1	





C - D - I - MAGNETO

Ref.	Part			
No.	Number	Description	Qty	Remarks
1	6H5-85550-10-00	ROTOR ASSEMBLY	1	
2	6H5-85560-01-00	BASE ASSEMBLY	1	
3	6H4-15359-03-94	HOUSING, OIL SEAL	1	
4	6H5-85520-00-00	COIL, CHARGE	1	
5	6H5-85533-01-00	COIL, LIGHTING	1	
6	6H5-85580-00-00	COIL, PULSER	1	
7	6H5-85580-10-00	COIL, PULSER	1	
8	6H5-85580-20-00	COIL, PULSER	1	
9	6H5-83354-00-00	WIRE, LEAD	1	
10	98580-05012-00	SCREW, PAN HEAD	6	
11	92990-05100-00	WASHER, SPRING	6	
12	92901-05600-00	WASHER, PLATE	6	
13	98511-06025-00	SCREW PAN HEAD	2	
14	92995-06100-00	WASHER, SPRING	2	
15	98580-06030-00	SCREW PAN HEAD	4	
16	92995-06100-00	WASHER, SPRING	4	
17	90464-03M15-00	CLAMP	2	
18	93102-23096-00	OIL SEAL	1	
19	90280-05049-00	KEY, WOODRUFF	1	
20	90179-16M05-00	NUT	1	
21	90201-16M44-00	WASHER, PLATE	1	
22	6H4-81332-00-00	PLATE, TIMING	1	
23	97985-05210-00	SCREW, WITH WASHER	1	
24	97313-06018-00	BOLT, HEXAGON	3	
25	92990-06600-00	WASHER, PLATE	3	

C - D - I - MAGNETO (40E - 40ET)


Ref. No.	Part Number	Description	Qty	Remarks
1	6H5-85550-00-00	ROTOR ASSEMBLY	1	
2	6H5-85560-01-00	BASE ASSEMBLY	1	
3	6H4-15359-03-94	HOUSING, OIL SEAL	1	
4	6H5-85520-00-00	COIL, CHARGE	1	
5	6H5-85533-01-00	COIL, LIGHTING	1	
6	6H5-85580-00-00	COIL, PULSER	1	
7	6H5-85580-10-00	COIL, PULSER	1	
8	6H5-85580-20-00	COIL, PULSER	1	
9	6H5-83354-00-00	WIRE, LEAD	1	
10	98580-05012-00	SCREW, PAN HEAD	6	
11	92990-05100-00	WASHER, SPRING	6	
12	92901-05600-00	WASHER, PLATE	6	
13	98511-06025-00	SCREW PAN HEAD	2	
14	92995-06100-00	WASHER, SPRING	2	
15	98580-06030-00	SCREW PAN HEAD	4	
16	92995-06100-00	WASHER, SPRING	4	
17	90464-03M15-00	CLAMP	2	
18	93102-23096-00	OIL SEAL	1	





ELECTRIC PARTS


Ref. No.	Part Number	Description	Qty	Remarks
1	6H5-85540-02-00	C.D.I. UNIT ASSEMBLY	1	
2	90465-13M36-00	CLAMP	1	
3	90119-06M51-00	BOLT, WITH WASHER	2	
4	6H4-82531-02-00	WIRE, LEAD	1	
5	97313-06014-00	BOLT	1	
6	92990-06600-00	WASHER, PLATE	1	
7	6H5-85570-00-00	IGNITION COIL ASSY	3	
8	90480-25161-00	GROMMET	1	
9	97313-06020-00	BOLT	3	
10	92990-06600-00	WASHER, PLATE	3	
11	663-82370-01-00	PLUG CAP ASSY	3	
12	689-82560-00-00	THERMOSWITCH ASSY	1	
13	90446-10M02-00	HOSE	1	
14	6G1-83557-00-00	TUBE	1	
15	90464-05M16-00	CLAMP	1	
16	97313-06014-00	BOLT	1	
17	92990-06600-00	WASHER, PLATE	1	



ELECTRIC PARTS (40E - 40ET)

Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-82105-01-00	WIRE HARNESS	1	
2	6G1-81970-61-00	RECTIFIER ASSEMBLY	1	
3	6G1-82151-00-00	FUSE	1	
4	98503-05025-00	SCREW, PAN HEAD	1	
5	92990-05600-00	WASHER, PLATE	1	
6	90465-18147-00	CLAMP	1	
7	6H4-48531-10-94	BRACKET, REMOTE CONTROL 1	1	
8	6H4-48532-10-94	BRACKET, REMOTE CONTROL 2	1	
9	6H4-42724-20-00	GROMMET	1	
10	6H4-42725-00-00	GROMMET	1	
11	676-42726-00-00	GROMMET	1	
12	6H4-82554-00-00	STAY, NEUTRAL SWITCH	1	
13	6H4-44173-01-00	LEVER, SHIFT CONTROL	1	
14	91690-30020-00	PIN, SPRING	1	
15	90464-15M27-00	CLAMP	1	
16	6H4-82588-00-00	PLATE	1	
17	97013-06012-00	BOLT	1	
18	6H4-82590-11-00	WIRE HARNESS ASSEMBLY ..	1	
	6H4-82590-22-00	WIRE HARNESS ASSEMBLY ..	1	UR
19	6H5-81950-00-00	RELAY ASSEMBLY	1	
20	92990-06200-00	WASHER, PLAIN	2	
21	97313-06025-00	BOLT	2	
22	92990-06600-00	WASHER, PLATE	2	
23	90387-06M05-00	COLLAR	2	
24	6H5-81920-00-00	TERMINAL ASSY	1	
25	97013-06012-00	BOLT	1	
26	92990-06600-00	WASHER, PLATE	1	


CONTINUED ON NEXT FRAME ►



ELECTRIC PARTS (40E - 40ET)


Ref. No.	Part Number	Description	Qty	Remarks
27	90465-18147-00	CLAMP	1	
28	6E5-82582-00-00	COVER, WIRE HARNESS	1	
29	6H4-82582-00-00	COVER, WIRE HARNESS	1	
30	90464-07M20-00	CLAMP	1	

OIL PUMP - TANK



Ref. No.	Part Number	Description	Qty	Remarks
1	90201-08M93-00	WASHER, PLATE	1	
2	6H4-11537-01-00	GEAR, DRIVEN	1	
3	6H1-13117-01-00	COLLAR, DISTANCE	1	
4	93210-13595-00	O-RING	1	
5	6H4-13200-04-00	OIL INJECTION PUMP ASSEMBLY	1	
6	6H1-13471-00-00	PLUG, DRAIN	1	
7	1YU-13187-00-00	GASKET, BREATHER BOLT ..	1	
8	93210-19M82-00	O-RING	1	
9	90109-06M39-00	BOLT	1	
10	90109-06M40-00	BOLT	1	
11	90445-07M44-00	HOSE (L250)	1	
12	90445-07M23-00	HOSE	1	
13	90445-07MA6-00	HOSE (L90)	1	
14	90468-07M02-00	CLIP	3	
15	90468-07M02-00	CLIP	3	
16	90464-07M20-00	CLAMP	1	
17	6H4-41241-01-00	ROD, LINK	1	
18	6H1-41237-00-00	JOINT, LINK	1	
19	90202-05088-00	WASHER, PLATE	1	
20	90468-05M03-00	CLIP	1	
21	95380-05600-00	NUT	1	
22	6R5-41237-00-00	JOINT, LINK	1	
23	6H4-21707-12-00	OIL TANK COMP.	1	
24	90446-09M08-00	HOSE	1	
25	90467-08004-00	CLIP	2	
26	6H4-21773-00-00	GROMMET	1	
27	6H1-21756-00-00	NET, FILTER	1	
28	6H4-21770-00-00	OIL TANK CAP ASSY	1	

CONTINUED ON NEXT FRAME ➤




OIL PUMP - TANK

Ref. No.	Part Number	Description	Qty	Remarks
29	6H4-24633-00-00	CHAIN, BALL	1	
30	6H4-24634-00-00	HOOK, CHAIN BALL	1	
31	6H4-21757-00-00	WASHER, SPECIAL 1	1	
32	90445-09M37-00	HOSE	1	
33	90467-08004-00	CLIP	2	
34	6A0-82317-00-00	DAMPER, IGNITION COIL	3	
35	624-42542-00-00	PIPE	3	
36	90201-06M02-00	WASHER, PLATE	3	
37	97395-06030-00	BOLT	2	
38	97395-06050-00	BOLT	1	
39	90445-07M87-00	HOSE (L110)	3	
40	6E9-13183-70-00	VALVE, CHECK	3	
41	90468-07M02-00	CLIP	6	
42	90445-11M17-00	HOSE	1	
43	90446-10M01-00	HOSE	2	
44	90467-10M04-00	CLIP	1	
45	6J8-21744-00-00	BREATHER	1	
46	90445-11M23-00	HOSE	1	
47	6H4-85720-20-00	OIL LVL.GAUGE ASSEMBLY ..	1	

OIL PUMP - TANK (40E - 40ET)

Ref. No.	Part Number	Description	Qty	Remarks
1	90201-08M93-00	WASHER, PLATE	1	
2	6H4-11537-01-00	GEAR, DRIVEN	1	
3	6H1-13117-01-00	COLLAR, DISTANCE	1	
4	93210-13595-00	O-RING	1	
5	6H4-13200-04-00	OIL INJECTION PUMP ASSEMBLY	1	
6	6H1-13471-00-00	PLUG, DRAIN	1	
7	1YU-13187-00-00	GASKET, BREATHER BOLT ..	1	
8	93210-19M82-00	O-RING	1	
9	90109-06M39-00	BOLT	1	
10	90109-06M40-00	BOLT	1	
11	90445-07M44-00	HOSE (L250)	1	
12	90445-07M23-00	HOSE	1	
13	90445-07MA6-00	HOSE (L90)	1	
14	90468-07M02-00	CLIP	3	
15	90468-07M02-00	CLIP	3	
16	90464-07M20-00	CLAMP	1	
17	6H4-41241-01-00	ROD, LINK	1	
18	6H1-41237-00-00	JOINT, LINK	1	
19	90202-05088-00	WASHER, PLATE	1	
20	90468-05M03-00	CLIP	1	
21	95380-05600-00	NUT	1	
22	6R5-41237-00-00	JOINT, LINK	1	
23	6H4-21707-04-00	OIL TANK COMP.	1	
24	90445-11M17-00	HOSE	1	
25	90464-11M23-00	CLAMP	1	
26	90467-11M08-00	CLIP	2	
27	6H4-21752-00-00	TUBE, FILLER 1	1	
28	90465-13M36-00	CLAMP	1	


CONTINUED ON NEXT FRAME ➤



OIL PUMP - TANK (40E - 40ET)


Ref. No.	Part Number	Description	Qty	Remarks
29	6H1-2176M-01-00	HOOK	1	
30	6H4-21770-00-00	OIL TANK CAP ASSY	1	
31	6H5-24633-00-00	CHAIN, BALL	1	
32	6J8-21758-00-00	WASHER, SPECIAL 2	1	
33	6H1-21757-00-00	WASHER, SPECIAL 1	2	
34	90445-11M03-00	HOSE	1	
35	90445-11M07-00	HOSE	1	
36	6J8-21744-00-00	BREATHER	1	
37	6E5-24378-00-00	PIPE, JOINT 4	1	
38	90467-10M04-00	CLIP	1	
39	90445-11M17-00	HOSE	1	
40	90446-10M01-00	HOSE	2	
41	6J8-13411-00-00	STRAINER, OIL	1	
42	6J8-13414-00-00	GASKET, STRAINER COVER ..	1	
43	6L2-13416-00-00	PIPE, OIL 1	1	
44	90467-08004-00	CLIP	1	
45	6A0-82317-00-00	DAMPER, IGNITION COIL	3	
46	624-42542-00-00	PIPE	3	
47	90119-06M65-00	BOLT, WITH WASHER	3	
48	90445-07M87-00	HOSE (L110)	3	
49	6E9-13183-70-00	VALVE, CHECK	3	
50	90468-07M02-00	CLIP	6	
51	90467-11M08-00	CLIP	1	
52	6H5-85720-12-00	OIL LEVEL GAUGE ASSEMBLY	1	
53	6H4-84342-00-00	SEAT, EMBLEM	1	
54	6H4-83589-00-00	GASKET	1	
55	92803-06014-00	UNAVAILABLE IN PRICE BOOK	1	
56	92990-06600-00	WASHER, PLATE	1	
57	90465-18147-00	CLAMP	1	


CONTINUED ON NEXT FRAME ➤



OIL PUMP - TANK (40E - 40ET)

Ref. No.	Part Number	Description	Qty	Remarks
58	6H4-84301-01-00	PILOT LIGHT ASSEMBLY 1 . . .	1	






REMOTE CONTROL CABLES

Ref. No.	Part Number	Description	Qty	Remarks
1	703-48210-13-00	REMOTE CONTROL ASSEMBLY (10P)	1	UR
	703-48272-12-00	REM-CON BOX, PRO 0	1	UR
2	ABA-CABLE-06-GY	REMOTE CONTROL CABLES - 6FT.	1	
	ABA-CABLE-07-GY	REMOTE CONTROL CABLES - 7FT.	1	
	ABA-CABLE-08-GY	REMOTE CONTROL CABLES - 8FT.	1	
	ABA-CABLE-09-GY	REMOTE CONTROL CABLES - 9FT.	1	
	ABA-CABLE-10-GY	REMOTE CONTROL CABLES - 10FT.	1	
	ABA-CABLE-11-GY	REMOTE CONTROL CABLES - 11FT.	1	
	ABA-CABLE-12-GY	REMOTE CONTROL CABLES - 12FT.	1	
	ABA-CABLE-13-GY	REMOTE CONTROL CABLES - 13FT.	1	
	ABA-CABLE-14-GY	REMOTE CONTROL CABLES - 14FT.	1	
	ABA-CABLE-15-GY	REMOTE CONTROL CABLES - 15FT.	1	
	ABA-CABLE-16-GY	REMOTE CONTROL CABLES - 16FT.	1	
	ABA-CABLE-17-GY	REMOTE CONTROL CABLES - 17FT.	1	
	ABA-CABLE-18-GY	REMOTE CONTROL CABLES - 18FT.	1	
	ABA-CABLE-19-GY	REMOTE CONTROL CABLES - 19FT.	1	
	ABA-CABLE-20-GY	REMOTE CONTROL CABLES - 20FT.	1	
	ABA-CABLE-21-GY	REMOTE CONTROL CABLES - 21FT.	1	

CONTINUED ON NEXT FRAME ➤





REMOTE CONTROL CABLES

Ref. No.	Part Number	Description	Qty	Remarks
2	ABA-CABLE-22-GY	REMOTE CONTROL CABLES - 22FT.	1	
	ABA-CABLE-23-GY	REMOTE CONTROL CABLES - 23FT.	1	
	ABA-CABLE-24-GY	REMOTE CONTROL CABLES - 24FT.REMOTE CONTROL CABLES - 24FT.	1	
	ABA-CABLE-25-GY	REMOTE CONTROL CABLES - 25FT.	1	
	ABA-CABLE-26-GY	REMOTE CONTROL CABLES - 26FT.	1	
	ABA-CABLE-27-GY	GREY CABLE 27 FOOT	1	
	ABA-CABLE-28-GY	REMOTE CONTROL CABLES - 28FT.	1	
	ABA-CABLE-29-GY	REMOTE CONTROL CABLES - 29FT.	1	
	ABA-CABLE-30-GY	REMOTE CONTROL CABLES - 30FT.	1	
	ABA-CABLE-32-GY	REMOTE CONTROL CABLES - 32FT.	1	
	ABA-CABLE-34-GY	REMOTE CONTROL CABLES - 34FT.	1	
	ABA-CABLE-36-GY	REMOTE CONTROL CABLES - 36FT.	1	
	ABA-CABLE-38-GY	GREY CABLE 38 FOOT	1	
	ABA-CABLE-40-GY	GREY CABLE 40 FOOT	1	
	ABA-CABLE-42-GY	GREY CABLE 42 FOOT	1	
	ABA-CABLE-44-GY	GREY CABLE 44 FOOT	1	
	ABA-CABLE-46-GY	GREY CABLE 46 FOOT	1	
	ABA-CABLE-48-GY	GREY CABLE 48 FOOT	1	
	ABA-CABLE-50-GY	GREY CABLE 50 FOOT	1	
3	6H4-48344-00-00	CABLE END, REMOTE CONTROL	2	

CONTINUED ON NEXT FRAME ➤


REMOTE CONTROL CABLES

Ref. No.	Part Number	Description	Qty	Remarks
4	90468-18008-00	CLIP	2	
5	6H4-48511-51-EK	HOOK STEERING	1	




STEERING GUIDE ATTACHMENT

Ref. No.	Part Number	Description	Qty	Remarks
1	689-61350-02-00	STEERING GUIDE ATTACHMENT KIT	1	
2	689-61351-01-00	. ROD, STEERING LINK	1	
3	90201-10M20-00	. WASHER, PLATE	2	
4	90185-09M01-00	. NUT, SELF-LOCKING	2	
5	90170-09M03-00	. NUT	1	
6	90387-10M42-00	. COLLAR	1	
7	6E5-61355-00-00	. BOLT	1	
8	90201-10M63-00	. WASHER, PLATE	1	
9	6E5-43145-00-00	. CAP, CLAMP BRACKET	1	
10	93210-16716-00	. O-RING	1	
11	688-61301-01-00	TIE BAR KIT (L:430-630MM) ..	1	UR
	ABA-DUALT-IE-BR	DUAL TIE BAR	1	UR
12	90185-09M01-00	. NUT, SELF-LOCKING	1	
13	90201-10M76-00	. WASHER, PLATE	2	
14	90101-09M70-00	. BOLT	2	
15	90170-09M05-00	. NUT	2	
16	6E5-61303-00-00	. STEERING EYE COMP.	2	
17	688-61311-11-00	. TIE BAR	1	UR
	6E5-61311-11-00	. TIE BAR	1	UR
18	95380-14700-00	. NUT	2	
19	6E5-61315-00-00	TIE BAR	1	
20	6E5-61313-00-00	. ADJUSTER	1	
21	90170-14M06-00	. NUT	1	



POWER TRIM & TILT COMP - PARTS


Ref. No.	Part Number	Description	Qty	Remarks
1	6H5-43840-04-EK	. POWER TILT ASSEMBLY . . .	1	
2	6H5-43841-00-00	. PISTON, SHUTTLE	1	
3	6H5-43861-00-00	. O-RING	1	
4	6H5-43891-00-00	. BUSHING 1	2	
5	6H5-43862-00-00	. O-RING	2	
6	6H5-43849-00-00	. PIN, VALVE SUPPORT	2	
7	6H5-43853-00-00	. SPRING, MAIN VALVE	1	
8	6H5-4382E-00-00	. ADAPTOR 2	2	
9	6H5-43863-00-00	. O-RING	2	
10	6H5-43846-02-00	. SCREW, MANUAL VALVE SEAT	1	
11	6H5-43864-00-00	. O-RING	1	
12	6H5-43865-00-00	. O-RING	1	
13	6H5-43875-00-00	. RING, SNAP	1	
14	6H5-43866-00-00	. O-RING	2	
15	6H5-43837-00-00	. GEAR, DRIVEN	1	
16	6H5-43836-00-00	. GEAR, DRIVE	1	
17	6H5-43858-10-00	. BALL	5	
18	6H5-43856-00-00	. SPRING, DOWN RELIEF	2	
19	6H5-43844-00-00	. PIN, VALVE SUPPORT	2	
20	6H5-43867-00-00	. O-RING	1	
21	6H5-43868-00-00	. O-RING	1	
22	6H5-43853-10-00	. SPRING, MAIN VALVE	1	
23	6H5-43859-00-00	. PIN, VALVE SUPPORT	6	
24	6H5-43855-01-00	. SPRING, UP RELIEF	1	
25	6H5-4386F-00-00	. RING, STRAIGHT	1	
26	6H5-43829-00-00	. PLUG, RESERVOIR	1	
27	6H5-43865-00-00	. O-RING	1	
28	6H5-4385A-00-00	. PISTON, TILT	1	




CONTINUED ON NEXT FRAME ➤

POWER TRIM & TILT COMP - PARTS

Ref. No.	Part Number	Description	Qty	Remarks
29	6H5-43801-00-00	. ROD	1	
30	6H5-43858-00-00	. BALL	5	
31	6H5-43857-00-00	. SPRING, ABSORBER VALVE	5	
32	6H5-43893-00-00	. WASHER	1	
33	6H5-43814-00-00	. PISTON, FREE	1	
34	6H5-43883-00-00	. O-RING	2	
35	6H5-43871-00-00	RING, BACK UP	2	
36	6H5-4381E-00-00	. BRACKET	1	
37	6H5-43896-00-00	. O-RING	1	
38	6H5-43873-00-00	. RING, BACK UP	1	
39	6H5-4381A-00-00	. SHAFT	5	
40	6H5-43812-00-00	. SEAL, DUST	1	
41	6H5-43897-00-00	. O-RING	1	
42	6H5-43880-01-00	. MOTOR ASSEMBLY	1	
43	6H5-43826-00-00	. PLUG, TAPER SCREW	3	
44	6H5-43811-00-00	. SCREW, CYLINDER END	2	
45	6H5-4381F-00-00	BRACKET	4	
46	6H5-43887-00-00	. BOLT, THROUGH	4	
47	6H5-43886-00-00	. BOLT	3	
48	6H5-43872-00-00	. RING, BACK UP	3	
49	91316-06020-00	. BOLT	4	
50	92995-06100-00	. WASHER, SPRING	12	
51	95600-12100-00	. NUT, U	1	
52	ø6G-18312-70-00	. UNAVAILABLE IN PRICE BOOK	1	
53	6H5-4388A-00-00	. BOLT	1	






REMOTE CONTROL COMPONENT PARTS

Ref. No.	Part Number	Description	Qty	Remarks
1	703-48210-13-00	REMOTE CONTROL ASSEMBLY (10P)	1	UR
	703-48272-12-00	REM-CON BOX, PRO 0	1	UR
	90890-55820-00	O/M KEY 4 1	1	UR
	90890-55821-00	O/M KEY 4 2	1	UR
	90890-55822-00	O/M KEY 4 3	1	UR
	90890-55823-00	O/M KEY 4 4	1	UR
	90890-55824-00	O/M KEY 4 5	1	UR
	90890-55825-00	O/M KEY 4 6	1	UR
	90890-55826-00	O/M KEY 4 7	1	UR
	90890-55827-00	O/M KEY 4 8	1	UR
	90890-55828-00	O/M KEY 4 9	1	UR
	90890-55829-00	O/M KEY 4 0	1	UR
	90890-55830-00	O/M KEY 4 1	1	UR
	90890-55831-00	O/M KEY 4 2	1	UR
	90890-55832-00	O/M KEY 4 3	1	UR
	90890-55833-00	O/M KEY 4 4	1	UR
	90890-55834-00	O/M KEY 4 5	1	UR
	90890-55835-00	O/M KEY 4 6	1	UR
	90890-55836-00	O/M KEY 4 7	1	UR
	90890-55837-00	O/M KEY 4 8	1	UR
	90890-55838-00	O/M KEY 4 9	1	UR
	90890-55839-00	O/M KEY 4 0	1	UR
	90890-55957-00	KEY (111)	1	UR
	90890-55958-00	KEY (112)	1	UR
	90890-55959-00	KEY (113)	1	UR
	90890-55960-00	KEY (121)	1	UR
	90890-55961-00	KEY (122)	1	UR
	90890-55962-00	KEY (123)	1	UR


CONTINUED ON NEXT FRAME ►



REMOTE CONTROL COMPONENT PARTS

Ref. No.	Part Number	Description	Qty	Remarks
2	676-82577-00-00	CAP, KEY	1	
	703-48261-10-00	ARM, THROTTLE	1	
3	703-48153-00-00	SHAFT, FREE ACCEL.	1	
4	703-48235-00-00	BUSHING	1	
5	703-48273-00-00	BUSHING 5	2	
6	703-48197-00-00	WASHER, WAVE 2	1	
7	703-48268-00-00	SPACER	1	
8	703-48263-00-00	BUSHING	1	
9	703-48264-00-00	THROTTLE, FRICTION	1	
10	95380-05600-00	NUT	1	
11	97380-05025-00	BOLT	1	
12	703-48265-00-00	SHAFT, FRICTION	1	
13	93430-06024-00	CIRCLIP	3	
14	703-48245-00-00	PLATE, LOCK	1	
15	703-48252-00-00	ROLLER, CAM	1	
16	701-48248-00-00	ROLLER, FREE ACCEL.	1	
17	703-48198-00-00	WASHER, WAVE	1	
18	703-48243-00-00	BUSHING	1	
19	703-48236-00-00	BUSHING 1	2	
20	703-48189-00-00	RETAINER	1	
21	703-48234-00-00	ROLLER, DETENT	1	
22	703-48345-01-00	CABLE END, REMOTE CONTROL 2	2	
23	703-48358-00-00	ANCHOR, CABLE	1	
24	703-48244-00-00	SPRING, FREE ACCEL.	1	
25	703-48238-00-00	SPRING, DETENT	5	
26	703-48246-00-00	SPACER	1	
27	703-48227-00-00	SPRING, NEUTRAL LOCK	1	
28	703-82594-00-00	CLAMP	1	


CONTINUED ON NEXT FRAME ►



REMOTE CONTROL COMPONENT PARTS

Ref. No.	Part Number	Description	Qty	Remarks
29	703-48226-00-00	PLATE, STOPPER	1	
30	703-48222-00-00	GRIP, CONTROL LEVER	1	
31	703-48223-00-00	LOCK, NEUTRAL	1	
32	703-48225-00-00	COVER	1	
33	703-48219-00-00	COVER, LEAD	1	
34	98780-05012-00	SCREW, FLAT HEAD	2	
35	98780-05016-00	SCREW, FLAT HEAD	7	
36	97395-08030-00	BOLT	1	
37	92990-08600-00	WASHER, PLATE	1	
38	98580-04010-00	SCREW, PAN HEAD	3	
39	98580-04006-00	SCREW, PAN HEAD	2	
40	98580-05010-00	SCREW, PAN HEAD	1	
41	98580-03014-00	SCREW, PAN HEAD	2	
42	703-48291-10-00	SCREW (M6)	3	
43	95380-06600-00	NUT, HEXAGON	3	
44	703-48293-10-00	SPACER, REMOTE CONTROL .	1	
45	701-48287-00-00	WASHER	3	
46	703-48215-00-00	GRAPHIC	1	
47	702-58217-00-00	UNAVAILABLE IN PRICE BOOK	1	
48	703-82510-10-00	MAIN SWITCH ASSEMBLY ...	1	
49	703-82574-00-00	SWITCH, CHOKE	1	
50	703-82531-00-00	WIRE, LEAD	1	
51	688-82575-01-00	ENGINE STOP SWITCH ASSY .	1	
52	682-82556-00-00	STOPPER	1	
53	688-8258A-20-00	EXTENSION, WIRE HARNESS .	1	
54	703-82540-00-00	NEUTRAL SWITCH ASSY	1	
55	703-83383-02-00	BUZZER	1	
56	703-48284-00-00	GROMMET	1	
57	90465-13169-00	CALMP	2	

CONTINUED ON NEXT FRAME ➤



REMOTE CONTROL COMPONENT PARTS

Ref. No.	Part Number	Description	Qty	Remarks
58	80L-26397-00-00	BAND	1	
59	703-48224-00-00	COVER, CONTROL LEVER ...	1	
	703-82563-01-00	TRIM & TILT SWITCH ASSY ..	1	UR
60	703-48221-00-00	LEVER, CONTROL	1	


OPTIONAL PARTS SWITCH PANEL - RIGGING ACCESSORIES


Ref. No.	Part Number	Description	Qty	Remarks
1	6H3-82540-00-00	NEUTRAL SWITCH ASSY	1	
	90890-55820-00	O/M KEY 4 1	1	UR
	90890-55821-00	O/M KEY 4 2	1	UR
	90890-55822-00	O/M KEY 4 3	1	UR
	90890-55823-00	O/M KEY 4 4	1	UR
	90890-55824-00	O/M KEY 4 5	1	UR
	90890-55825-00	O/M KEY 4 6	1	UR
	90890-55826-00	O/M KEY 4 7	1	UR
	90890-55827-00	O/M KEY 4 8	1	UR
	90890-55828-00	O/M KEY 4 9	1	UR
	90890-55829-00	O/M KEY 4 0	1	UR
	90890-55830-00	O/M KEY 4 1	1	UR
	90890-55831-00	O/M KEY 4 2	1	UR
	90890-55832-00	O/M KEY 4 3	1	UR
	90890-55833-00	O/M KEY 4 4	1	UR
	90890-55834-00	O/M KEY 4 5	1	UR
	90890-55835-00	O/M KEY 4 6	1	UR
	90890-55836-00	O/M KEY 4 7	1	UR
	90890-55837-00	O/M KEY 4 8	1	UR
	90890-55838-00	O/M KEY 4 9	1	UR
	90890-55839-00	O/M KEY 4 0	1	UR
	90890-55957-00	KEY (111)	1	UR
	90890-55958-00	KEY (112)	1	UR
	90890-55959-00	KEY (113)	1	UR
	90890-55960-00	KEY (121)	1	UR
	90890-55961-00	KEY (122)	1	UR
	90890-55962-00	KEY (123)	1	UR
2	676-82577-00-00	CAP, KEY	1	
	6H4-82554-00-00	STAY, NEUTRAL SWITCH	1	UR

CONTINUED ON NEXT FRAME ➤

OPTIONAL PARTS SWITCH PANEL - RIGGING ACCESSORIES

Ref. No.	Part Number	Description	Qty	Remarks
2	6H4-82554-10-00	STAY, NEUTRL SWITCH	1	UR
3	6H4-82553-00-00	EXTENSION, WIRE LEAD	1	
4	6H4-44173-01-00	LEVER, SHIFT CONTROL	1	UR
	6H4-44173-10-00	LEVER, SHIFT CONTRL	1	UR
5	91690-30020-00	PIN, SPRING	1	
6	704-82570-02-00	PANEL SWITCH ASSEMBLY ..	1	
7	689-82571-02-00	PANEL, SWITCH	1	
8	704-82510-02-00	MAIN SWITCH ASSEMBLY ...	1	
9	6K1-82574-00-00	SWITCH, CHOKE	1	
10	688-82575-01-00	ENGINE STOP SWITCH ASSY .	1	
11	682-82556-00-00	STOPPER	1	
12	704-82581-00-00	STAY, CORD CLAMP	1	
13	97080-05012-00	BOLT	1	
14	92990-05100-00	WASHER, SPRING	1	
15	95303-05700-00	NUT	1	
16	688-83383-11-00	BUZZER	1	
17	90149-05M05-00	SCREW	4	
18	95380-05600-00	NUT	4	
19	92990-05100-00	WASHER, SPRING	4	
20	92990-05600-00	WASHER, PLATE	4	
21	688-8258A-50-00	EXTENSION, WIRE HARNESS .	1	
22	688-8258A-10-00	EXTENSION, WIRE HARNESS .	1	UR
	688-8258A-30-00	EXTENSION, WIRE HARNESS .	1	UR






OPTIONAL PARTS GAUGES & COMPONENT PARTS


Ref. No.	Part Number	Description	Qty	Remarks
1	6Y5-83540-14-00	TACHOMETER ASSEMBLY ...	1	
2	688-83516-00-00	BULB (12V-1.7W, T10)	1	
3	688-83536-00-00	SOCKET, METER	1	
4	6Y5-83523-00-00	DAMPER	1	
5	6Y5-83514-00-00	PLATE, FITTING	1	
6	95380-05600-00	NUT	2	
7	92990-05100-00	WASHER, SPRING	2	
8	6Y5-83510-10-00	SPEEDOMETER ASSEMBLY ..	1	
9	688-83516-00-00	BULB (12V-1.7W, T10)	1	
10	688-83536-00-00	SOCKET, METER	1	
11	6Y5-83523-00-00	DAMPER	1	
12	6Y5-83514-00-00	PLATE, FITTING	1	
13	688-83557-00-00	TUBE	1	
14	90465-11M10-00	CLAMP	2	
15	95380-05600-00	NUT	2	
16	92990-05100-00	WASHER, SPRING	2	
17	90601-31402-00	CLIP, NYLON 4	5	
18	97780-40116-00	SCREW, TAPPING	5	
19	6Y5-83660-10-00	WATER PRESSURE METER ASSEMBLY (6Y5-83660-00-00) .	1	
20	6Y5-83518-00-00	BULB (12V-1.7W, T6.5)	1	
21	6Y5-83536-00-00	SOCKET, METER	1	
22	688-83664-00-00	DAMPER	1	
23	688-83665-00-00	PLATE, FITTING	1	
24	95380-05600-00	NUT	2	
25	92990-05100-00	WASHER, SPRING	2	
26	688-83667-00-00	SENDER	1	
27	688-83666-00-00	TUBE	1	
28	663-83668-00-00	NUT, NIPPLE	2	

CONTINUED ON NEXT FRAME ➤



OPTIONAL PARTS GAUGES & COMPONENT PARTS


Ref. No.	Part Number	Description	Qty	Remarks
29	90430-14115-00	GASKET	1	
30	90601-31402-00	CLIP, NYLON 4	5	
31	97780-40116-00	SCREW, TAPPING	5	



OPTIONAL PARTS GAUGES & COMPONENT PARTS

Ref. No.	Part Number	Description	Qty	Remarks
1	6Y5-83504-01-00	HOUR METER ASSEMBLY . . .	1	
2	688-83664-00-00	DAMPER	1	
3	6Y5-83577-00-00	PLATE, FITTING	1	
4	6Y5-83536-00-00	SOCKET, METER	1	
5	6Y5-83518-00-00	BULB (12V-1.7W, T6.5)	1	
6	95303-04600-00	NUT	2	
7	92901-04100-00	WASHER, SPRING	2	
8	6Y5-83590-00-00	WATER TEMPERATURE ASSEMBLY	1	
9	6Y5-83518-00-00	BULB (12V-1.7W, T6.5)	1	
10	6Y5-83536-00-00	SOCKET, METER	1	
11	688-83664-00-00	DAMPER	1	
12	6Y5-83544-00-00	PLATE, FITTING	1	
13	95303-04600-00	NUT	2	
14	92901-04100-00	WASHER, SPRING	2	
15	688-83591-00-00	THERMO UNIT	1	
16	90430-14115-00	GASKET	1	
17	6Y5-83503-00-00	VOLTMETER ASSEMBLY	1	
18	6Y5-83544-00-00	PLATE, FITTING	1	
19	688-83664-00-00	DAMPER	1	
20	6Y5-83536-00-00	SOCKET, METER	1	
21	6Y5-83518-00-00	BULB (12V-1.7W, T6.5)	1	
22	95303-04600-00	NUT	2	
23	92901-04100-00	WASHER, SPRING	2	
24	6Y5-85750-10-00	FUEL METER ASSEMBLY	1	
25	6Y5-83518-00-00	BULB (12V-1.7W, T6.5)	1	
26	6Y5-83536-00-00	SOCKET, METER	1	
27	688-83664-00-00	DAMPER	1	
28	6Y5-83544-00-00	PLATE, FITTING	1	


CONTINUED ON NEXT FRAME ►




OPTIONAL PARTS GAUGES & COMPONENT PARTS

Ref. No.	Part Number	Description	Qty	Remarks
29	95303-04600-00	NUT	2	
30	92901-04100-00	WASHER, SPRING	2	

OPTIONAL PARTS LEAD WIRE-ACCESSORIES




Ref. No.	Part Number	Description	Qty	Remarks
1	6Y5-82149-00-00	WIRE, LEAD (BLUE)	1	UR
2	6Y5-82117-00-00	WIRE, LEAD (BLACK)	1	UR
3	6Y5-82521-00-00	WIRE, LEAD (YELLOW)	1	UR
4	6Y5-83553-00-00	WIRE, LEAD	1	
5	1E6-82151-00-00	FUSE (10A)	1	



REPAIR KIT 1


Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-W0001-02-00	PWR HEAD GSKT KT	1	
2	6H4-11181-A0-00	GASKET, CYLINDER HEAD 1	1	
3	6H4-11193-00-00	GASKET, HD.COVER 1	1	
4	90430-14115-00	GASKET	1	
5	6J8-12414-A0-00	GASKET, COVER	1	
6	6H4-41114-A0-00	GASKET, EXHAUST OUTER COVER	2	
7	6H4-15369-A1-00	GASKET, OIL SEAL HOUSING	1	
8	93101-16M36-00	OIL SEAL	2	
9	93102-25M28-00	OIL SEAL	1	
10	93210-57M09-00	O-RING	1	
11	6H4-13621-A1-00	GASKET, VALVE SEAT	2	
12	6H4-14198-01-00	GASKET	3	
13	6H3-14457-01-00	SEAL	3	
14	6H4-14984-00-00	GASKET, FLOAT CHAMBER	3	
15	93210-37M25-00	O-RING	1	
16	650-24431-A0-00	GASKET, FUEL PUMP 1	1	
17	6H4-45113-A0-00	GASKET, UPPER CASING	1	
18	6H4-W0093-03-00	CARBURETOR REPAIR KIT	1	
19	6H4-14198-01-00	GASKET	3	
20	676-14966-00-00	CAP	3	
21	6H3-14590-00-00	NEEDLE VALVE ASSY	3	
22	663-14159-00-00	CLIP	3	
23	676-14186-00-00	PIN, FLOAT	3	
24	6H4-14985-00-00	FLOAT	3	
25	6H4-14548-00-00	PIN, FLOAT ARM	3	
26	6H4-14984-00-00	GASKET, FLOAT CHAMBER	3	
27	97980-04114-00	SCREW, WITH WASHER	3	
28	93210-04230-00	O-RING	3	

CONTINUED ON NEXT FRAME ➤



REPAIR KIT 1


Ref. No.	Part Number	Description	Qty	Remarks
29	6H4-14147-00-00	O-RING	3	
30	692-14923-00-00	SCREW, PILOT	3	



REPAIR KIT 2

Ref. No.	Part Number	Description	Qty	Remarks
1	6H4-W0001-20-00	LWR UNIT GSKT KIT	1	
2	6H4-45114-A1-00	GASKET, UPPER CASING	1	
3	6H4-41134-A0-00	GASKET, EXHAUST MANIFOLD	1	
4	6H4-41133-00-00	GASKET, EXHAUST MANIFOLD 1	1	
5	663-45123-00-00	GASKET, MUFFLER	1	
6	90430-08020-00	GASKET	3	
7	93210-49046-00	O-RING	1	
8	663-44315-00-00	GASKET, WATER PUMP	1	
9	663-44324-00-00	GASKET, CARTRIDGE	1	
10	663-44316-00-00	GASKET, WATER PUMP	1	
11	93210-41042-00	O-RING	1	
12	93101-23070-00	OIL SEAL	2	
13	Φ93-21006-M9-80	UNAVAILABLE IN PRICE BOOK	1	
14	93101-22067-00	OIL SEAL	2	
15	6H4-W0078-00-00	WATER PUMP REP. KT	1	
16	663-44322-00-00	INSERT, CARTRIDGE	1	
17	6H4-44352-02-00	IMPELLER	1	
18	663-44315-00-00	GASKET, WATER PUMP	1	
19	663-44323-00-00	OUTER PLATE, CARTRIDGE ..	1	
20	663-44324-00-00	GASKET, CARTRIDGE	1	
21	663-44316-00-00	GASKET, WATER PUMP	1	
22	97395-08055-00	BOLT	2	
23	97395-08045-00	BOLT	2	
24	663-44366-00-00	DAMPER, WATER SEAL	1	
25	90280-03024-00	KEY, WOODRUFF	1	
26	6H4-W0078-0A-00	CHROME PUMP KIT	1	
27	670-44322-01-00	INSERT, CARTRIDGE	1	
28	670-44321-00-00	INNER PLATE, CARTRIDGE ..	1	

CONTINUED ON NEXT FRAME ➤



REPAIR KIT 2

Ref. No.	Part Number	Description	Qty	Remarks
29	670-44323-00-00	OUTER PLATE, CARTRIDGE . .	1	

